

Suzuki C-10 Color Display

The New Suzuki C-10 Color Display is a LED high resolution screen that has very sharp, crisp lines and is extremely easy to read. It has a glass front screen whether it be sunscreen, salt, or UV rays, your screen will never blur or fade like a plastic screen. The C-10 has its mounting points in the front so there is no need to crawl under your console to mount it. It connects to Suzuki's digital harnesses with one easy connection. Save your favorite programming and update the display using the Mini USB port. The C-10 is able to monitor functions such as RPM's, Speed, Water Pressure, Fuel Level, Fuel Consumption, Motor Temperature, Trim Level, Hours, or Volts. The C-10 is able to monitor up to 2 engines simultaneously.



Benefits

- Bright, full color 320 x 240 LED screen makes it easier to see menus and screen detail in both full sunlight and night operation
- Fits standard 3 3/8" gauge cutout
- Displays data for one or two engines per gauge
- Use preconfigured pages or create your own!
- Micro USB for software updates
- Power and data through single NMEA 2000 micro-C connector
- Low profile front mount – 8mm of dash (rear mount option for "glass dash" installations)

Color Display Update Cable

990C0-99C10-CBL



Suzuki Color Display Kit

990C0-00C10-KIT Suzuki Color Display Kit includes:

Part Number	Description	Qty	Part Number	Description	Qty
990C0-00C10	Suzuki Color Display	1	990C0-88113	Female Terminator	1
990C0-88114	Male Terminator	1	990C0-88110	NMEA "T"	3
990C0-88112	Power Cable	1	990C0-88149-350	Interface Cable	1



GPS Antenna with Compass

Suzuki has upgraded its GPS Antenna to include compass heading.

990C0-88122 GPS Antenna with Compass Heading



Interface Cables

DF9.9B thru DF300 Suzuki Outboards can connect to the system using the exclusive Suzuki Interface Cable. (Adaptor Cable also needed for DF150G/175G/200AP/250AP/300AP applications.)

Part Number	Description	Software Version
990C0-88149-350	Engine Interface Cable	3.5
990C0-88149-290	Engine Interface Cable	2.9



Adaptors

Adaptor must be used with Engine Interface to connect the DF150G/175G/200AP/250AP/300AP outboard to the system.

990C0-88131	Single Engine Adaptor (not shown)
990C0-88132	Dual Engine Adaptor (not shown)
990C0-88133	Triple Engine Adaptor (not shown)
990C0-88132 x2	Quad Engine Adaptor (not shown)
990C0-88136	NMEA 2000 Adaptor - to connect at engine SDS connector

K8 Adaptor (not shown)

Required in order to put new style Interface cable on older system with round SDS connection.

990C0-88141



NMEA 2000 Extension Cables

NMEA 2000 Extension Cable allows compatible sensors or other devices can be added by the use of T-Connectors throughout the system.

990C0-88104	2' Connection cable
990C0-88105	6' Connection cable
990C0-88107	15' Connection cable
990C0-88108	25' Connection cable



Power Cable

Fused(3A) lead connects extension cable to the power source.

990C0-88112 Single Power Cable



Quad Power Node

Allows network to be powered from multiple power sources (key switch, accessory switch, etc...).

990C0-88130 Quad Power Node



NMEA Adaptor

Used to connect a new style NMEA device net connector to an older network with Blue T's.

990C0-88137 NMEA Device to Blue "T"

Used to connect an early Blue Connector device to the later NMEA T.


990C0-88029 Blue Device to NMEA "T"



T-Connector

T-Connector for NMEA 2000 system.

990C0-88110 T-Connector



Terminating Resistors

120 ohm Terminating Resistors are required for any open cable ends in the NMEA 2000 system.

990C0-88113 Terminator - Female

990C0-88114 Terminator - Male

Sensors



Fluid Level Sensor

Monitors fluid levels such as fuel, live well water level, etc. 10ft cable.

990C0-88216 Fluid Level Sensor



Speed Sensor

Paddle wheel-type speed sensor. 10ft cable.

990C0-88117 Speed Wheel



Temperature Sensor

Surface Water Temperature sensor. 10ft cable.

990C0-88118 Temperature Sensor



Water Pressure Sensor

990C0-88139 Water Pressure Sensor

34970-98J02 Water Pressure Kit

Suzuki Precision Control

Suzuki's flagship 300AP 4-stroke leads in power, performance and technology. Following are some high-tech items to help take advantage of Suzuki's leading edge technology.

Suzuki Precision Control (SPC) Electronic Throttle And Shift System

For fly by wire models only



Single Engine SPC Box Only (Replacement Units)

67200-98J03 Single Engine SPC Box only



Flush Mount SPC Box Only (Replacement Units)

67200-98J22 Flush Mount SPC Box only



Dual and Triple Engine SPC Box only (Replacement Units)

67200-98J13 Dual and Triple Engine SPC Box only



Single Engine SPC Kits

	67000-98J69 Flush-Mount Station Kit	67000-98JE0 Single Station Binacle Kit	67000-98J19 Dual Station Kit
67200-98J03	Binacle-Mount RC Box	1	1
67200-98J22	Flush-Mount RC Box	1	
37100-98J04	Main Power Key Switch Assy	1	
37100-98J11	Single Engine Control Panel Assy	1	1
38500-93J90	Warning Buzzer	1	1
37803-93J04	Emergency Switch Panel		1
36625-98J10	Battery Lead	1	
36770-98J11	Boat Control Module (BCM)	1	1
36775-98J00	BCM Holder (L)	1	1
36776-98J00	BCM Holder (R)	1	1
33911-88BLO	BCM-Connect Cap	1	1
33925-93J00	BCM Cushion	1	1
36623-98J20	BCM #1 Wiring Harness	1	
36624-98J02	BCM #2 Wiring Harness		1
36622-98J00	Dual Station Main Harness		1
33926-98J00	Terminal Resistor	2	
37860-87L00	Troll Mode Switch Panel	1	1

Dual Engines SPC Kits

	67000-98J60 Single Station Kit	67000-98J39 Dual Station Kit
67200-98J13	Dual Binnacle RC Box	1
37100-98J04	Main Power Key Switch Assy	1
37100-98J21	Dual Engine Control Panel Assy	1
38500-93J90	Warning Buzzer	1
37803-93J04	Emergency Stop Switch Panel	1
36625-98J10	Battery Lead	1
36770-98J11	Boat Control module (BCM)	1
36775-98J00	BCM Holder (L)	1
36776-98J00	BCM Holder (R)	1
33925-93J00	BCM Cushion	1
36623-98J30	BCM #1 Wiring Harness	1
36624-98J11	BCM #2 Wiring Harness	1
33926-98J00	Terminal Resistor	2
36621-98J00	Dual Engine Single Station Harness	1
36622-98J00	Dual Station Main Harness	1
37860-87L00	Troll Mode Switch Panel	1

Triple Engines SPC Kits

	67000-98J49 Single Station Kit	67000-98J59 Dual Station Kit
67200-98J13	Binnacle-Mount RC Box	1
37100-98J04	Main Power Key Switch Assy	1
37100-98J31	Triple Engine Control Panel Assy	1
38500-93J90	Warning Buzzer	1
37803-93J04	Emergency Switch Panel	1
36625-98J10	Battery Lead	1
36770-98J11	Boat Control module (BCM)	1
36775-98J00	BCM Holder (L)	1
36776-98J00	BCM Holder (R)	1
33925-93J00	BCM Cushion	1
36623-98J30	BCM #1 Wiring Harness	1
36624-98J11	BCM #2 Wiring Harness	1
33926-98J00	Terminal Resistor	2
36621-98J10	Triple Engine Single Station Harness	1
36622-98J00	Dual Station Main Harness	1
37860-87L00	Troll Mode Switch Panel	1

Quadruple Engines SPC Kits

	67000-98J71 Single Station Kit	67000-98J80 Dual Station Kit
67200-98J13	Binnacle-Mount RC Box	1
37100-98J04	Main Power Key Switch Assy	1
37100-98J21	Dual Engine Control Panel Assy	2
38500-93J90	Warning Buzzer	2
37803-93J04	Emergency Switch Panel	1
36625-98J10	Battery Lead	2
36770-98J20	Boat Control module (BCM)	2
36775-98J00	BCM Holder (L)	2
36776-98J00	BCM Holder (R)	2
33925-93J00	BCM Cushion	2
36623-98J40	BCM Quadruple Wiring Harness	1
33926-98J00	Terminal Resistor	4
36621-98J00	Dual Engine Single Station Harness	2
36622-98J00	Dual Station Main Harness	2
37860-87L00	Troll Mode Switch Panel	1

Counter Rotation Adaptor

36612-98J10	Regular Rotation Selector
36612-98J20	Counter Rotation Selector



Suzuki Precision Control

Suzuki's flagship 300AP 4-stroke leads in power, performance and technology. Following are some high-tech items to help take advantage of Suzuki's leading edge technology.



Control Panel Assemblies



Triple Engine Control Panel Assy

37100-98J31 Triple Engine Control Panel Assy



Main Power Key Switch Assembly

Main Power Key Switch required for use with switch control panels listed above. Includes key.

37100-98J04 Main Power Key Switch Assembly

Emergency Stop Switch Panel Assembly

Includes: Emergency Stop Switch with Panel and Lanyard. Required at each station.

37803-93J04 Emergency Stop Switch Panel Assy



**Dual Engine Control Panel Assy**

- | | |
|-----------------------|--------------------------------|
| 37100-98J21 | Dual Engine Control Panel Assy |
| 37100-98J21 x2 | Quad Engine Control Panel Assy |

**Single Engine Control Panel Assy**

- | | |
|--------------------|----------------------------------|
| 37100-98J11 | Single Engine Control Panel Assy |
|--------------------|----------------------------------|

Battery Lead

- | |
|--------------------|
| 36625-98J10 |
|--------------------|

**Battery Isolator Lead Sets**

Used for charging an auxiliary battery.

- | | |
|--------------------|------------------------------------|
| 33830-98J02 | DF300 2007-2011 only |
| 33830-98J11 | DF150G/175G/200AP/250AP/300A/300AP |

**Wiring Harnesses**

Main Wiring Harness. Order length as needed for rigging applications.



- | | |
|--------------------|---------------------------|
| 36620-98J30 | 21' (6.5m) Wiring Harness |
| 36620-98J40 | 31' (9.5m) Wiring Harness |



- | | |
|--------------------|---|
| 36620-98J50 | 6.5' (2m) Wiring Harness Extension
(Optional; order as needed) |
|--------------------|---|

Replacement Wiring Harness (not shown)

- | | |
|--------------------|--------------------------------------|
| 36621-98J00 | Dual Engine Single Station Harness |
| 36621-98J10 | Triple Engine Single Station Harness |
| 36622-98J00 | Dual Station Main Harness |
| 36770-98J11 | Boat Control Module (BCM) |



- | | |
|--------------------|--|
| 36623-98J20 | BCM Harness No1
for Single Engine Single Station |
| 36623-98J30 | BCM Harness No1
for Multiple Engines Single Station |



- | | |
|--------------------|--|
| 36624-98J02 | BCM Harness No 2
for Single Engine Second Station |
| 36624-98J11 | BCM Harness No 2
for Multiple Engine Second Station |
| 36623-98J40 | BCM Quadruple Harness |