

Maintenance Items



[Return to PPT Website](#)

Thermostats

	2-Stroke Application	Part Number
General Information	3, 4, 5, 6, 8	6E5-12411-02-00
	9.9, 15 (~95)	6F5-12411-03-00
Rigging Estimate Guide (Diagrams)	9.9, 15 (96~)	6E5-12411-30-00
	20, 40, 50, C50, P50	6E5-12411-30-00
	25 Three Cylinder	688-12411-11-00
	25 Two Cylinder	6E5-12411-30-00
	C25	6F5-12411-03-00
Rigging Components	30 (~91)	6E5-12411-30-00
	30 (92~)	688-12411-11-00
	C30 (~92)	6F5-12411-03-00
Electrical Components	C30 (93~)	6E5-12411-02-00
	40, 50	6E5-12411-30-00
	C40, C55 (~97)	6F5-12411-03-00
Engine Accessories	C40 (98~)	6E5-12411-30-00
	60, C60, E60, P60, 70, C70	6H3-12411-11-00
	C75, P75, E75, C80, C85, 90, C90	688-12411-11-00
	115, 130, 150, 175, 200, 225, 250	6E5-12411-30-00
	B115, C115, C150, D150, DX150	6E5-12411-30-00
Propellers	P115, P150, PX150, P200	6E5-12411-30-00
	S115, S130, SX150, SX200	6E5-12411-30-00
	S225, SX225, S250, SX250	6E5-12411-30-00
	V150, VX150, V200, VX200	6E5-12411-30-00
	VX225, VX250	6E5-12411-30-00
Maintenance Items	VZ150, VZ175, VZ200 (2.6L)	6E5-12411-30-00
	Z150, Z175, Z200 (2.6L)	6E5-12411-30-00
	VZ200, VZ225, VZ250, VZ300 (3.3L)	60V-12411-00-00
	Z250, Z300 (3.3L)	60V-12411-00-00
	4-Stroke Application	Part Number
Oils & Lubes	F2.5, F4, F4A, F6, F6A, F8, T8	66M-12411-01-00
	F9.9, T9.9, F15, F25, T25	66M-12411-01-00
Detailing & Trailer Supplies	F15C-F20	6AH-12411-00-00
	F30, F40, F40A, F50, T50	66M-12411-01-00
	F60, T60, F70	66M-12411-01-00
	F75, F90	67F-12411-01-00
	F80, F100 (~00)	66M-12411-01-00
Accessories & Apparel	F80, F100 (01~)	67F-12411-01-00
	F115	60V-12411-00-00
	F115B	
Generators & Accessories	F150, F200, F225, F250, F250B	67F-12411-01-00
	VF200, VF225, VF250 (4.2L)	67F-12411-01-00
	F225, F250, F300 (4.2L)	6CE-12411-00-00
	F300, F350 (V8)	6AW-12411-00-00



Select Yamaha Item # to Open Part in PPT Online Store

Maintenance Items

Thermostat Gaskets



Application	Part Number
F2.5 (03~)	68D-E2414-A0-00
F4 (99~)	68D-E2414-A0-00
F4A, F6A	68D-E2414-A0-00
F6, F8, T8, F9.9, FT9.9, T9.9	6G8-12414-A0-00
9.9, 15	682-12414-A1-00
F9.9-2, T9.9-2	62Y-12414-00-00
F15, F25, T25, F30	62Y-12414-00-00
F15C, F20	6AH-12414-00-00
20	61A-12414-A0-00
25, 30, 40	61A-12414-A0-00
C25, CV25, C30, CV30	655-12414-A1-00
C40, CV40 (~97)	6E9-12414-A1-00
C40, C50 (98~)	61A-12414-A0-00
P40	61A-12414-A0-00
F40, F50, T50, F60, T60, F70	62Y-12414-00-00
C55, E48	663-12414-A0-00
C75, E75, P75, C80, C80	688-12414-A1-00
C85, CV85, C90	688-12414-A1-00
90, B90, B115	688-12414-A1-00
115, 130, 150, 175, 200	688-12414-A1-00
P115, P150, PX150, P175, P200	688-12414-A1-00
S115, S130, S150, S175, S200	688-12414-A1-00
D150, DX150	688-12414-A1-00
F150	63P-12414-00-00
SX150, SX200, V150, VX150, V175	688-12414-A1-00
ProV150	688-12414-A1-00
VZ150, VZ175, VZ200 (2.6L)	688-12414-A1-00
Z150, Z175, Z200 (2.6L)	688-12414-A1-00
V200, V225	61A-12414-A0-00
VX200, VX225, VX250	61A-12414-A0-00
VZ200, VZ225, VZ250, VZ300 (3.3L)	60V-12414-A0-00
Z250, Z300	60V-12414-A0-00
225 (2.6L)	688-12414-A1-00
225, 250, S225, S250, SX225, SX250	61A-12414-A0-00

- General Information
- Rigging Estimate Guide (Diagrams)
- Rigging Components
- Electrical Components
- Engine Accessories
- Propellers
- Maintenance Items
- Oils & Lubes
- Detailing & Trailer Supplies
- Accessories & Apparel
- Generators & Accessories