



Rigging Order Guide Index

Description

Page

Single Engine

Single Engine with Mechanical Side Mount Controls

2-1

Single Engine with Mechanical Binnacle Controls

2-8

Single Engine With DEC Side Mount Controls

2-18

Single Engine With DEC Binnacle Controls

2-21

Select Yamaha Outboard Part
Numbers to open each product
within the ONLINE STORE

General
Information

Rigging Estimate
Guide (Diagrams)

Rigging
Components

Electrical
Components

Engine
Accessories

Propellers

Maintenance
Items

Oils
& Lubes

Detailing &
Trailer Supplies


Accessories
& Apparel

Generators
& Accessories

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Mechanical Side Mount Controls - Analog Gauges




Parts order list for basic installation:

Quantity	Description	Part Number
1	703 Side Mount Control with 10 Pin Harness	703-48207-1A-10
1	Analog Tachometer	6Y7-83540-90-00
1	Analog Trim Meter	6Y7-83670-50-00
1	Dual Fuse Harness	6Y5-83553-N0-00
1	Yellow Wire Extension	6Y5-82521-00-00
1	2005~ Trim and Oil Harness	See List ¹

¹ 2005~ Trim and Oil Harness

16.4 ft.	6Y5-83653-00-00
19.7 ft.	6Y5-83653-10-00
23 ft.	6Y5-83653-20-00
26.3 ft.	6Y5-83653-30-00
30 ft.	6Y5-83653-40-00
35 ft.	6Y5-83653-50-00

Single Engine with Mechanical Side Mount Controls - Analog Gauges



Parts order list for basic installation:

Quantity	Description	Part Number
1	703 Side Mount Control with 10 Pin Harness	703-48207-1A-10
1	Analog Tachometer	6Y7-83540-90-00
1	Analog Speedometer	6Y7-83510-10-00
1	Analog Trim Meter	6Y7-83670-50-00
1	Analog Water Temp Gauge	6Y7-83590-10-00
1	Analog Volt Meter	6Y7-83503-10-00
1	Dual Fuse Harness	6Y5-83553-N0-00
2	Yellow Wire Extension	6Y5-82521-00-00
2	Blue Wire Extension	6Y5-82149-00-00
2	Black Wire Extension	6Y5-82117-00-00
1	2005~ Trim and Oil Harness	See List ¹


¹ 2005~ Trim and Oil Harness

16.4 ft.	6Y5-83653-00-00
19.7 ft.	6Y5-83653-10-00
23 ft.	6Y5-83653-20-00
26.3 ft.	6Y5-83653-30-00
30 ft.	6Y5-83653-40-00
35 ft.	6Y5-83653-50-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Mechanical Side Mount Controls - Multifunction Gauges




Parts order list for basic installation:

Quantity	Description	Part Number
1	703 Side Mount Control with 10 Pin Harness	703-48207-1A-10
1	Multifunction Tachometer Kit	6Y5-8350T-83-00
1	Dual Fuse Harness	6Y5-83553-N0-00
1	Trim and Oil Harness	See List ¹

¹ 2005~ Trim and Oil Harness

16.4 ft.	6Y5-83653-00-00
19.7 ft.	6Y5-83653-10-00
23 ft.	6Y5-83653-20-00
26.3 ft.	6Y5-83653-30-00
30 ft.	6Y5-83653-40-00
35 ft.	6Y5-83653-50-00

Single Engine with Mechanical Side Mount Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	703 Side Mount Control with 10 Pin Harness	703-48207-1A-10
1	Command Link Tachometer	6Y8-8350T-01-00
1	Command Link Speed / Fuel Gauge	6Y8-83500-01-00
2	Multi-Hub Assembly	6Y8-81920-01-00
1	Power Lead, 8 ft.	6Y8-83553-01-00
1	Cap, 2 Pin	6Y8-82582-01-00
3	Cap, 4 Pin	6Y8-82582-11-00
1	Speed Sensor Kit	60V-8A4L1-13-00
1	Fuel Sender and GPS Wire Lead	6Y8-8356N-01-00
1	Pigtail Harness, Engine to Rear Hub, 12 ft.	6Y8-82521-51-00
2	Pigtail Harness, Hub to Gauge	See List ¹
1	Main Bus Hub, Rear Hub to Front Hub	See List ²

¹Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00


²Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00

General Information

Rigging Estimate Guide (Diagrams)

Rigging Components



Engine
Accessories

Propellers


Maintenance
ItemsOils
& Lubes

Detailing & Trailer Supplies

Accessories
& Apparel

Generators & Accessories

Single Engine with Mechanical Flush Mount Controls - Multifunction Gauges



Parts order list for basic installation:

Quantity	Description	Part Number
1	6X0 Standard Flush Mount Control	6X0-48206-12-00
1	Single Engine Key Switch	704-82570-10-00
1	Multifunction Tachometer	6Y5-8350T-83-00
1	Multifunction Speedometer	6Y5-83570-56-00
1	Speedometer Tube, 8.0 m	6Y5-83557-10-00
2	Clamp	90465-10098-00
10	Clamp	90465-13M39-00
1	Dual Fuse Harness	6Y5-83553-N0-00
1	10-Pin Main Harness	See List ¹
1	Trim and Oil Harness (2005~)	See List ²


¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00

² 2005~ Trim and Oil Harness

16.4 ft.	6Y5-83653-00-00
19.7 ft.	6Y5-83653-10-00
23 ft.	6Y5-83653-20-00
26.3 ft.	6Y5-83653-30-00
30 ft.	6Y5-83653-40-00
35 ft.	6Y5-83653-50-00

Single Engine with Mechanical Flush Mount Controls - 6YC Display



Parts order list for basic installation:

Quantity	Description	Part Number
1	6X3 Premium Flush Mount Control Box	6X3-48206-01-00
1	Single Engine Key Switch	64D-82570-21-00
1	6YC Display Kit	6YC-0E83C-00-00
1	10-Pin Main Harness	See List ¹
1	Main Buss Harness, Rear Hub to Front Hub	See List ²
1	Pigtail Harnesses, Front Hub to Display	See List ³

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00


² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00

³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Single Engine with Binnacle Controls - Multifunction Gauges



Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Multifunction Tachometer	6Y5-8350T-83-00
1	Multifunction Speedometer	6Y5-83570-S6-00
1	Speedometer Tube, 8.0 m	6Y5-83557-10-00
2	Clamp	90465-10098-00
10	Clamp	90465-13M39-00
1	Dual Fuse Harness	6Y5-83553-N0-00
1	10-Pin Main Harness	See List ¹
1	Trim and Oil Harness (2005~)	See List ²

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00


² 2005~ Trim and Oil Harness

16.4 ft.	6Y5-83653-00-00
19.7 ft.	6Y5-83653-10-00
23 ft.	6Y5-83653-20-00
26.3 ft.	6Y5-83653-30-00
30 ft.	6Y5-83653-40-00
35 ft.	6Y5-83653-50-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Binnacle Controls - Command Link®




Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Command Link® Round Gauge Kit with In-line Hub	6Y8-0E83R-81-00
1	10-Pin Main Harness	See List ¹

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00

Single Engine with Binnacle Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Command Link® Round One Gauge Kit	6Y8-0E83R-61-00
1	10-Pin Main Harness	See List ¹
1	Main Buss Harness, Rear Hub to Front Hub	See List ²
1	Pigtail Harnesses, Front Hub to Gauges	See List ³

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00

² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00


³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Binnacle Controls - Command Link®




Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Command Link® Round Gauge Kit with In-line Hub	6Y8-0E83R-91-00
1	10-Pin Main Harness	See List ¹

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00



Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Command Link® Round Gauge Kit with In-line Hub	6Y8-0E83R-71-00
1	10-Pin Main Harness	See List ¹
1	Main Buss Harness, Rear In-line Hub to Front Hub	See List ²
2	Pigtail Harnesses, Front Hub to Gauges	See List ³

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00

² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00


³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Binnacle Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Command Link Tachometer	6Y8-8350T-01-00
1	Command Link Speed / Fuel Gauge	6Y8-83500-01-00
2	Multi-Hub Assembly	6Y8-81920-01-00
1	Power Lead, 8 ft.	6Y8-83553-01-00
1	Cap, 2 Pin	6Y8-82582-01-00
3	Cap, 4 Pin	6Y8-82582-11-00
1	Speed Sensor Kit	60V-8A4L1-13-00
1	Fuel Sender and GPSWire Lead	6Y8-8356N-01-00
1	Pigtail Harness, Engine to Rear Hub, 12 ft.	6Y8-82521-51-00
1	10-Pin Main Harness	See List ¹
1	Main Buss Harness, Rear Hub to Front Hub	See List ²
2	Pigtail Harnesses, Front Hub to Gauges	See List ³

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00


² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00

³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Single Engine with Binnacle Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	Command Link® Round Two Gauge Kit	6Y8-0E83R-41-00
1	10-Pin Main Harness	See List ¹
1	Main Buss Harness, Rear Hub to Front Hub	See List ²
2	Pigtail Harnesses, Front Hub to Gauges	See List ³

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00

² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00


³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Binnacle Controls - 6YC Display



NEW!

Parts order list for basic installation:

Quantity	Description	Part Number
1	Premium 704 Single Engine Binnacle Control Box	704-48205-P1-00
1	Single Engine Key Switch	704-82570-10-00
1	6YC Display	6YC-83710-00-00
1	Dual Fuse Harness	6Y5-83553-N0-00
1	Orange Extension Harness	6Y8-82553-60-00
2	Single Hubs	6Y8-81920-11-00
1	GPS / Fuel Harness	6Y8-8356N-01-00
1	10-Pin Main Harness	See List ¹
1	Pig Tail Harness, Engine to Rear Hub	See List ²
1	Pig Tail Harness, Front Hub to Display	See List ²

¹ 10-Pin Harnesses

16 ft.	688-8258A-50-00
20 ft.	688-8258A-60-00
23 ft.	688-8258A-70-00
26 ft.	6K1-8258A-40-00
31.2 ft.	61B-8258A-01-00

² Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

NEW!



¹ 10-Pin Harnesses

² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00


³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with Binnacle Controls - 6YC Display



Parts order list for basic installation:

Quantity	Description	Part Number
1	6YC Display Kit with 704 Remote Control	6YC-0E83C-10-00
1	Main Buss Harness, Rear Hub to Front Hub	See List ¹
1	Pigtail Harnesses, Front Hub to Display	See List ²


¹ Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00

² Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Single Engine with DEC Flush Mount Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Flush Mount Control	CL-1FA
1	Single Engine Key Switch	64D-82570-21-00
1	Command Link Tachometer	6Y8-8350T-01-00
1	Command Link Speed / Fuel Gauge	6Y8-83500-01-00
1	Multi-Hub Assembly	6Y8-81920-01-00
1	Power Lead, 8 ft.	6Y8-83553-01-00
1	Multi-Hub Resistor	6Y8-85371-01-00
1	Fuel Sender and GPS Wire Lead	6Y8-8356N-01-00
1	DEC Main Harness	See List ¹
1	Pigtail Harness, Control box to hub	See List ²
2	Pigtail Harness, Hub to gauges	See List ²

¹DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00

²Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with DEC Flush Mount Controls - 6YC Display



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Flush Mount Control	CL-1FA
1	Single Engine Key Switch	64D-82570-21-00
1	6YC Display Kit	6X6-0E83C-00-00
1	DEC Main Harness	See List ¹
1	Main Bus Harness, Control Box Adaptor to Hub	See List ²
1	Pigtail Harness, Hub to Display	See List ³

¹ DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00


² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00

³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Single Engine with DEC Flush Mount Controls - Command Link® Plus



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Flush Mount Control	CL-1FA
1	Single Engine Key Switch	64D-82570-21-00
1	Command Link Plus® Display Kit	MAR-CLPDU-KT-20
1	Command Link Plus® Display Installation Kit	MAR-CLPDI-KT-10
1	DEC Main Harness	See List ¹
1	Main Bus Harness, Control Box Adaptor to Hub	See List ²
1	Pigtail Harness, Hub to Display Harness	See List ³

¹ DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00

² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00


³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with DEC Binnacle Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Single Main Station Control	CL-1MA
1	Single Engine Key Switch	6X6-82570-31-00
1	DEC Single Engine Round Gauge Kit	6X6-0E83R-21-00
1	DEC Main Harness	See List ¹
2	Pigtail Harness, Hub to Gauges	See List ²


¹DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00

²Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Single Engine with DEC Binnacle Controls - Command Link®



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Single Main Station Control	CL-1MA
1	Single Engine Key Switch	6X6-82570-31-00
1	Command Link Tachometer	6Y8-8350T-01-00
1	Command Link Speed / Fuel Gauge	6Y8-83500-01-00
1	Multi-Hub Assembly	6Y8-81920-01-00
1	Power Lead, 8 ft.	6Y8-83553-01-00
1	Multi-Hub Resistor	6Y8-85371-01-00
1	Fuel Sender and GPSWire Lead	6Y8-8356N-01-00
1	DEC Main Harness	See List ¹
1	Pigtail Harness, Control box to hub	See List ²
2	Pigtail Harness, Hub to gauges	See List ²

¹ DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00

² Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with DEC Binnacle Controls - 6YC Display



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Single Main Station Control	CL-1MA
1	Single Engine Key Switch	6X6-82570-31-00
1	6YC Display Kit	6X6-0E83C-00-00
1	DEC Main Harness	See List ¹
1	Main Bus Harness, Control Box Adaptor to Hub	See List ²
1	Pigtail Harness, Hub to Display	See List ³

¹ DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00


² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00

³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Single Engine with DEC Binnacle Controls - Command Link® Plus



Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® Single Main Station Control	CL-1MA
1	Single Engine Key Switch	6X6-82570-31-00
1	Command Link Plus® Display Kit	MAR-CLPDU-KT-20
1	Command Link Plus® Display Installation Kit	MAR-CLPDI-KT-10
1	DEC Main Harness	See List ¹
1	Main Bus Harness, Control Box Adaptor to Hub	See List ²
1	Pigtail Harness, Hub to Display Harness	See List ³

¹ DEC Main Harnesses

20 ft.	6X6-8258A-00-00
23 ft.	6X6-8258A-10-00
26 ft.	6X6-8258A-20-00
33.5 ft.	6X6-8258A-30-00
39 ft.	6X6-8258A-40-00

² Main Buss Harnesses

1 ft.	6Y8-82553-01-00
10 ft.	6Y8-82553-50-00
15 ft.	6Y8-82553-11-00
20 ft.	6Y8-82553-21-00
25 ft.	6Y8-82553-31-00
30 ft.	6Y8-82553-41-00


³ Pigtail Harnesses

1 ft.	6Y8-82521-01-00
2 ft.	6Y8-82521-11-00
3 ft.	6Y8-82521-21-00
6 ft.	6Y8-82521-31-00
9 ft.	6Y8-82521-41-00
12 ft.	6Y8-82521-51-00

Rigging Estimate Guide

Select Yamaha Outboard Part Numbers to open each product within the ONLINE STORE

Single Engine with DEC Binnacle Controls -2nd Station



¹ CLP Primary Harness		² DEC Secondary Harness	
16 ft.	6X6-8258A-G0-00	16 ft.	6X6-8258A-B1-00
26 ft.	6X6-8258A-H0-00	26 ft.	6X6-8258A-D1-00
40 ft.	6X6-8258A-J0-00	40 ft.	6X6-8258A-F1-00

Parts order list for basic installation:

Quantity	Description	Part Number
1	Command Link Plus® 2 nd Station Single Engine Control Box	CL-1SA
1	Command Link Plus® 2 nd Station Switch Set	6X6-W0035-70-00
1	CLP Primary Harness	See List 1
1	DEC Secondary Harness	See List ²